



# LIVE PLANT INSTALLATION THROUGH RECPS



NORTH  
AMERICAN  
GREEN



PLAN VIEW



1. INSTALL BLANKETS USING APPROPRIATE STAPLE PATTERN AND ACCORDING TO APPLICATION REQUIREMENTS (I.E. SLOPE, CHANNEL, OR SHORELINE). CUT AN "X" PARALLEL TO PREDOMINANT FLOW DIRECTION THROUGH THE BLANKET USING SCISSORS OR UTILITY KNIFE. THE LENGTH OF CUTS SHOULD EXCEED THE DIAMETER OF THE PLANTS ROOT BALL BY APPROXIMATELY 12" (30cm) WITHOUT LIMITING PLANT PLACEMENT ACTIVITIES (I.E. PLANT ROOT BALL EQUALS 6" (15cm) CUT "X" 18 (46cm) IN LENGTH).

NOTE: IF PLANT ROOT BALL DOES NOT EXCEED 3" (8cm) IN DIAMETER THEN SIMPLY CUT A SINGLE CUT PARALLEL TO PREDOMINANT FLOW DIRECTION. THE CUT ONLY NEEDS TO EXCEED ROOT BALL DIAMETER BY APPROXIMATELY 6" (15cm).

CAUTION: DO NOT PLACE EXCAVATED SOIL FROM PLANTING PROCESS ON BLANKET. THIS MAY RESULT IN DAMAGE TO THE BLANKET AND REDUCED EROSION CONTROL PERFORMANCE.

2. AFTER PLACING PLANT AND REPLACING PREVIOUSLY REMOVED SOIL FOLD FLAPS OF BLANKET BACK INTO PLACE.
3. STAPLE/STAKE CUTS CLOSED STARTING AS CLOSE TO THE PLANT STEM AS POSSIBLE AND CONTINUE PLACING STAPLES EVERY 6" (15cm) WORKING OUTWARDS (SEE PLAN VIEW ABOVE).
4. CONTINUE PLACING STAPLES ALONG SEAM UNTIL ALL CUTS HAVE BEEN SECURELY FASTENED CLOSED (SEE DIAGRAM ABOVE).

NOTE: IN SOME INSTANCES ADDITIONAL BLANKET MAY BE REQUIRED TO PROTECT ALL EXPOSED SOIL DUE TO MOUNDING ASSOCIATED WITH PLANTS ROOT BALL INSTALLATION.